



Fixing the Remote Pull Station

- Remote pull station shall be fixed on a strong and flat surface.
- Remote pull station shall be fixed via 4 pcs of fixing screws on the surface.
- Remote pull station shall be fixed **between 140 and 170 cm.** height from floor.
- Remote pull station shall be fixed at minimum 2 m. far away from hood.
- Remote pull station shall be fixed in an easily seen and easily reachable location.
- Both **END OF LINE** or **MID-LINE** installation is available for Manual Pull Station.
(Please check the images below)



END OF LINE Installation of MANUAL PULL STATION (P300)



MID-LINE Installation of MANUAL PULL STATION (P300)